

INSTRUCTIONS

The clock is shipped with a small white plastic piece between the crown and body of the clock which prevents the clock from running and draining the battery during transit. Remove the small plastic piece by pulling it straight out. With the plastic piece removed, the crown will be in the up position. Turn the crown clockwise or counter-clockwise to set the time-of-day. With the time-of-day set, press down on the crown until it “clicks” and locks into the down position. With the crown in the down position, the seconds hand will begin moving and the clock will maintain the time-of-day. To adjust/set the time-of-day after initial setup, lift up on the crown until it “clicks” and locks into the up position (with the crown in the up position, the clock will stop). Turn the crown to set the time-of-day, then press down on the crown to start the clock.

The clock is powered by an internal long-life battery and does not require winding. The crown is used only for setting the time-of-day.